8' X 20' SET UP INSTRUCTIONS

TWO PEOPLE REQUIRED!

© 2016 Grosh Scenic Rentals

CONTENTS:

Two rolling duffel bags



One gorgeous Grosh 8' X 20' backdrop graphic



Two Pop Up frames



Four metal stabilizer feet



1 Remove 2 bags from hard case. Backdrop graphic will be folded in a clear plastic zip-lock bag.



2 On a clean floor, stretch frames outward completely so that the locking arms are as close together as possible. Lay the two frames side by side on the floor with the Velcro side facing up



3 Once both frames are next to each other, carefully align all purple locking arms on the outer perimeter of the frame together and click into place. After outer perimeter locking arms are completed, click the interior arms into place.







TIP! Make sure to click locking arms straight to avoid breaking.

4 Be sure to line up both frames side by side. Use arrows on the Velcro to position the frames exactly. Take printed backdrop graphic out of the plastic bag. Make sure you have a large clean area to open up the backdrop. Two people opening out the drop makes it easier.





5 Attach the Velcro from the graphic to the frame working from the center out. The graphic itself is what keeps the two frames tethered together. Look for the center "C" marking on the back of the backdrop graphic marked in ink along the Velcro at the top and bottom. Velcro end flaps to the corners to complete seamless look.





6 With at least 2 people, gently lift the 20' wide span with the backdrop completely attached and walk it upward.



7 Slide stabilizer feet over 4 equally spaced hubs on the bottom of the frame. Attach two on the outside of frame, and two anywhere near center. Feet will fit snuggly.





8 Stunning! Enjoy the 20-foot Pop-up Drop by Grosh!